


SDL1000X/X-E Firmware Update Instructions

WARNING:


Upgrade takes several minutes!

Do not shut down the instrument during the upgrade!


1. Copy the update file to the USB flash drive.
2. Insert the USB flash drive into the USB host interface on the front panel of SDL1000X/X-E.
3. Press the “Shift” softkey and the “CP” softkey to get into Utility interface.
4. Press the “System” softkey.




5. Press the “Page1/2” softkey to Page2/2.



6. Press the “Upgrade” softkey.




7. Press the down arrow key to select the external drive (the USB flash drive). Then press the right arrow key to find the files(.ADS)



8. Press the “OK” softkey. The instrument will be automatically upgraded. When the upgrade finishes, it will restart itself.



9. Check the firmware version. Please press the “Shift” softkey and the “CP” softkey to get into the utility interface.



10. Press the “System” softkey and press the “System info” softkey and you will can view the SW Version.



WARNING:

Upgrade takes several minutes!

Do not shut down the instrument during upgrade!