

Firmware Update Instructions

Notes : 1. During the updating, do not cut off the power or pull out the U-disk.

2. If your analyzer has an earlier version (V1.x.x.x), it can not upgrade to" V2.x.x.x" version and the "V2.x.x.x" version also can not downgrade to the earlier version

1. Please firstly copy the update file (.ADS) to U-disk.
2. Insert the U-disk to the USB port.
3. Press **System** button and then press **System Info**, we can enter **Firmware Update** interface.




Figure 1 System menu

4. Press **Firmware Update** and then enter the file system (or you can press **File** button to enter the file system).




Figure 2 System information interface

- Set the **Browser** to **file**. Use the knob or touch screen to select the right update firmware. Then press **Open/Load**, we will see an information window. Press the **Enter** and will see the upgrading information ('hourglass and upgrading now, please wait'). This upgrade program will take about 2~3 minutes.




Figure 3 Update

- When the device upgrading finished, it will restart by itself. We can check the version information in system info(System--System info).




Figure 4 System info